




## SP B.4: Reference coatings for ITER and DEMO

**JSI activities in 2022:** XPS analysis of selected Be-D samples

**Matjaž Panjan, Janez Kovač**

Jožef Stefan Institute, Ljubljana, Slovenia



Jožef Stefan Institute



This work has been carried out within the framework of the EUROfusion Consortium and has received funding from the Euratom research and training programme 2014-2018 under grant agreement No 633053. The views and opinions expressed herein do not necessarily reflect those of the European Commission.

# XPS analysis of selected Be-D samples





- **Task:** Demonstrate the value of XPS technique for Be-D analysis. Possibly observe nature of chemical bond between Be and D.
- **Samples:** Be-D thin films with 5% and 10% of D prepared by magnetron sputtering using different substrate temperatures

sample	60190520_2_3	60190523_2_3	60190515_2_3	60190527_2_3	60190607_2_2
<i>thin film</i>	Be-D	Be-D	Be-D	Be-D	Be-D
<i>thickness</i>	5 µm				
<i>D (at.%)</i>	5 %	5 %	10 %	10 %	10 %
<i>substrate</i>	tungsten	tungsten	tungsten	tungsten	tungsten
<i>sample photo</i>					
<i>preparation method</i>	reactive DC magnetron sputtering				
<i>gas mixture</i>	Ar/D	Ar/D	Ar/D	Ar/D	Ar/D
<i>substrate temperature</i>	room temperature	400 °C	room temperature	200 °C	JET-like T cycle ~60s: 60°C → 200°C ~540s: 200°C → 60°C

# X-ray photoelectron spectroscopy



## Principle of XPS measurements




## Information obtained from XPS spectra

- **identification and quantification** of elements (except H, D and He)
- **chemical state** of elements
- **depth profiles** when combined with ion-etching

# XPS surface analysis of Be-D samples




*XPS survey spectra (C, O, Be, N)*



All Be-D samples show similar XPS spectra

*Composition of surface*




## D (5%) samples




- similar composition for both samples

## D (10%) samples

- C decreases
- Be and O increase




# Depth profiles of Be-D samples





# Depth profiles of Be-D samples



- **Similar depth profiles** for three analyzed samples
- **BeO thickness** ~4-5 nm. More oxygen present in sample deposited at 400 °C
- **Carbon** is present on the surface as contamination and as carbide in subsurface region (~3-6 at.%)
- **Nitrogen** is present as nitride in subsurface region (1-2 at.%)